

# Technovision

## TV-66K BUT20P4 firmware

### Quick Reference Guide 01-2012

Technovision  
1845 Sandstone Manor, #2  
Pickering, Ontario  
L1W 3X9  
P:(905) 420-5153  
F:(905) 420-0753  
www.technovision.com

#### Installation Instruction:

- Make sure the power to the DV-66/75 player is OFF before attaching the TV-66K.
- Connect the DV66KC control cable (RJ11-RJ11) to the IO port of the DV-66/75. Connect the other end of the cable to connector TS1 on the TV66K.

#### Button Wiring

Button (track)#	Terminals to attach the button to
1	1 and 6
2	1 and 7
3	1 and 8
4	1 and 10
5	2 and 6
6	2 and 7
7	2 and 8
8	2 and 10
9	3 and 6
10	3 and 7
11	3 and 8
12	3 and 10
13	4 and 6
14	4 and 7
15	4 and 8
16	4 and 10
17	5 and 6
18	5 and 7
19	5 and 8
20	5 and 10

#### Wiring Example

For button 1 you would connect a wire from the COMMON (COM) connector on the button to terminal 1 and then connect a wire from the NORMALLY OPEN (NO) connector on the button to terminal 6.

#### Wiring additional DV66 or DV75 players

You may purchase CC66 control cables to attach more players to the TV66K. On these cables, attach either the BLACK or YELLOW wire to terminal#10 (GROUND) and the RED or GREEN wire to terminal #9 (TTL transmit signal)

#### System Diagram

