

Wiring Instructions for a Technovision Button (with 12VLED) to the TM21

When using a 12V button LED within a button, connect the 12 volts DC from the TM21 to the + side of the LED.

Connect the BSY (provides the ground level) output from the TM21 to the ground side “-“ of the button LED.

