

Wiring instructions for CHAP30 For the Technovision LD48

PORTA on the PARALLEL port of the LD48 is used for the columns (8-conductor harness), and PORTB (4-conductor harness) is used for the rows on the keypad matrix. The chart below included the pin number on the PARALLEL port of the LD48 as well as the standard wire colour used in any custom harnesses.

8 conductor cable Harness

	6 RED	18 BLUE	5 YELLOW	17 ORANGE	4 GREEN	16 BLACK	3 BROWN	15 WHITE
10 RED	1	2	3	4	5	6	7	8
22 BLUE	9	10	11	12	13	14	15	16
9 YELLOW	17	18	19	20	21	22	23	24
21 ORANGE	25	26	27	-	-	-	-	-

For example: For Chapter 20 you would connect the **ORANGE** cable on the 8 conductor harness with the **YELLOW** wire on the 4 conductor harness. These wires should be connected to the C (common) and NO (normally open) connector on the button.

The Pioneer DVD-V7400 should be set up for 4800 baud with the power on setting at T00:C00